

16. TROUBLESHOOTING

ENGINE DOES NOT START OR
IS HARD TO START..... 16-2

ENGINE LACKS POWER 16-3

POOR PERFORMANCE AT LOW
AND IDLE SPEED..... 16-5

POOR PERFORMANCE AT HIGH SPEED 16-5

POOR HANDLING..... 16-6

ENGINE DOES NOT START OR IS HARD TO START

1. Carburetor Inspection

Check the fuel flow to carburetor.

Is fuel reaching the carburetor?

- NO** - • Clogged fuel line and strainer
• Clogged fuel tank breather hose

YES - GO TO STEP 2.

2. Spark Test

Perform a spark test.

Is there a good spark?

- NO** - • Faulty spark plug
• Fouled spark plug
• Faulty ignition control module
• Broken or shorted spark plug wire
• Faulty igniting pulse generator
• Faulty engine stop switch or ignition switch
• Loose or disconnected ignition system wires

YES - GO TO STEP 3.

3. Spark Plug Inspection

Remove and inspect spark plug.

Is the spark plug in good condition?

- NO** - • Flooded carburetor
• Choke valve closed
• Air cleaner dirty

YES - GO TO STEP 4.

4. Engine Start Condition

Start by following the normal procedure.

Does the engine start but then stop?

- YES** - • Improper choke operation
• Carburetor incorrectly adjusted
• Intake pipe leaking
• Improper ignition timing (faulty ignition coil or ignition pulse generator)
• Fuel contaminated

NO - GO TO STEP 5.

5. Cylinder Compression Inspection

Test cylinder compression.

Is the compression normal?

- NO** - • Valve clearance too small
• Valve stuck open
• Worn cylinder and piston ring
• Damaged cylinder head gasket
• Seized valve
• Improper valve timing

ENGINE LACKS POWER

1. Drive Train Inspection

Raise wheel off the ground and spin by hand.

Does the wheel spin freely?

- NO** – • Brake dragging
• Worn or damaged wheel bearings

YES – GO TO STEP 2.

2. Tire Pressure Inspection

Check the tire pressure.

Is the tire pressure correct?

- NO** – • Faulty tire valve
• Punctured tire

YES – GO TO STEP 3.

3. Clutch Inspection

Accelerate rapidly from low to second.

Does the engine speed change accordingly when clutch is released?

- NO** – • Clutch slipping
• Worn clutch discs/plates
• Warped clutch discs/plates
• Weak clutch spring
• Additive in engine oil

YES – GO TO STEP 4.

4. Engine Performance Inspection

Accelerate lightly.

Does the engine speed increase?

- NO** – • Choke valve closed
• Clogged air cleaner
• Restricted fuel flow
• Clogged muffler
• Pinched fuel tank breather hose

YES – GO TO STEP 5.

5. Ignition Timing Inspection

Check the ignition timing.

Is the ignition timing normal?

- NO** – • Faulty ignition control module
• Faulty ignition pulse generator

YES – GO TO STEP 6.

6. Cylinder Compression Inspection

Test cylinder compression.

Is the compression normal?

- NO** – • Valve clearance too small
• Worn cylinder and piston ring
• Leaking head gasket
• Seized valve
• Improper valve timing

YES – GO TO STEP 7.

7. Carburetor Inspection

Check the carburetor for clogs.

Is the carburetor clogged?

- YES** – Carburetor not serviced frequently enough

NO – GO TO STEP 8.

8. Spark Plug Inspection

Remove and inspect the spark plug.

Is the spark plug in good condition?

- NO** – • Plug not serviced frequently enough
• Incorrect spark plug heat range

YES – GO TO STEP 9.

9. Engine Oil Inspection

Check the oil level and condition.

Is the engine oil in good condition?

- NO** – • Oil level too high
• Oil level too low
• Contaminated oil

YES – GO TO STEP 10.

10. Lubrication Inspection

Remove cylinder head cover and inspect lubrication.

Is the valve train lubricated properly?

- NO** – • Clogged oil passage
• Clogged oil control orifice

YES – GO TO STEP 11.

11. Over Heating Inspection

Check for engine over heating.

Is the engine over heating?

- YES** – • Excessive carbon build-up in combustion chamber
• Use of poor quality fuel
• Clutch slipping
• Lean fuel mixture
• Wrong type of fuel

NO – GO TO STEP 12.

12. Engine Knocking Inspection

Accelerate or run at high speed.

Does the engine knock?

- YES** – • Worn piston and cylinder
• Wrong type of fuel
• Excessive carbon build-up in combustion chamber
• Ignition timing too advanced (faulty ignition control module)
• Lean fuel mixture

POOR PERFORMANCE AT LOW AND IDLE SPEED

1. Carburetor Air Screw Inspection

Check the carburetor air screw adjustment.

Is the air screw correct?

NO – (page 5-13)

YES – GO TO STEP 2.

2. Intake Manifold Leaking Inspection

Check for leaks in the intake Manifold.

Is there leaking?

YES – • Loose carburetor mounting bolts
• Damaged insulator

NO – GO TO STEP 3.

3. Spark Test

Perform a spark test.

Is there a good spark?

NO – • Faulty or fouled spark plug
• Faulty ignition control module
• Faulty ignition coil
• Broken or shorted spark plug wire
• Faulty engine stop switch or ignition switch
• Faulty ignition pulse generator
• Loose or disconnected ignition system wires

YES – GO TO STEP 4.

4. Ignition Timing Inspection

Check the ignition timing.

Is the ignition timing normal?

NO – Improper ignition timing (Faulty ignition control module)

POOR PERFORMANCE AT HIGH SPEED

1. Fuel Line Inspection

Disconnect the fuel hose at the carburetor.

Does the fuel flow freely?

NO – • Clogged fuel line
• Clogged fuel tank breather hose
• Faulty fuel valve
• Clogged fuel strainer

YES – GO TO STEP 2.

2. Carburetor Inspection

Remove the carburetor and check for clogged jets.

Are the jets clogged?

YES – Clean

NO – GO TO STEP 3.

3. Valve Timing Inspection

Check the valve timing.

Is the valve timing correct?

NO – Cam sprocket not installed properly

YES – GO TO STEP 5.

4. Ignition Timing Inspection

Check the ignition timing.

TROUBLESHOOTING

Is the ignition timing normal?

NO – • Faulty ignition control module
• Faulty ignition pulse generator

YES – GO TO STEP 5.

5. Valve Spring Inspection

Check the valve springs.

Is the valve spring free length normal?

NO – Faulty spring

YES – Not weak

POOR HANDLING

Steering is heavy

- Steering stem adjusting nut too tight
- Damaged steering head bearings

Either wheel is wobbling

- Excessive wheel bearing play
- Bent rim
- Improper installed wheel hub
- Swingarm pivot bearing excessively worn
- Bent frame

The motorcycle pulls to one side

- Faulty shock absorber
- Front and rear wheel not aligned
- Bent fork
- Bent swingarm
- Bent axle